Procedure for filling the Conmurra Autofill hydrobath

This procedure <u>should not</u> need to be done every time you use the hydrobath, only if the wash tank/rinse tank valve was not in the 12 o'clock position when draining the rinse tank.

Filling the rinse tank

Ensure that the left hand drain valve (blue flowline) is in the 12 o'clock, closed position.

Ensure that the wash tank/rinse tank selector valve (black Zetco) is in the 12 o'clock position.

Connect a water source to the fitting on the rear of the hydrobath and turn on the tap.

Allow the tank to fill completely.

Move the wash tank/rinse tank selector valve to rinse tank. This will allow the fresh water to gravity flow into the pump and purge the air from the pump cavity.

Turn the pump on and water will now move from the rinse tank through the shower head to either fill the wash tank or to rinse the dog.

Note:- If, when you turn the pump on, no water comes through the shower head, turn the pump off, place the shower head on the floor, outside the hydrobath and wait for water to dribble out of the hose (approx.15 seconds).

Pick the hose up and point it into the hydrobath. Turn the pump on and water will flow and purge any remaining air out of the pump cavity. Bubbles will be visible in the hose.

You will now be able to use the hydrobath.

Procedure for emptying the Conmurra Autofill hydrobath

Emptying the rinse tank

When emptying the rinse tank, ensure that the wash tank/rinse tank selector valve is in the 12 o'clock position. If this step is not carried out, the water in the pump will be syphoned from the pump cavity and may cause an airlock. This will prevent the pump from moving water when next used.

Move the left hand drain valve to the 9 o'clock position.

The water remaining in the rinse tank will drain out the waste pipe.

Note:- If an airlock does occur, refer to the filling procedure, detailed earlier.

When the tank is empty, move the drain valve to the 12 o'clock position.

This will set the hydrobath up for re filling.

It is recommended to drain the rinse tank and remove the round cover at the end of the week and vacation periods, to allow the rinse tank to vent. Refit the cover prior to filling the tank.